

HIDEAWAY POCKET DOORS

Fitting instructions Hideaway Cavity Widening Kit (catalogue no. 61601) (for doors up to 50mm thick)

This kit will increase the cavity width to 62mm and must be used when the door thickness is between 44mm and 50mm

Note: The plywood spacers are pre-cut to suit the Hideaway H42 pocket door kit when being used with a 1067mm (3'6") wide door.
For narrower doors or where H36 or H30 kits are being installed the plywood spacers need to be cut to the appropriate length before fixing.

Contents:
3 floor plates.
2 wood strips each 1092mm x60mmx6mm
2 wood strips each 755mmx20mmx6mm
Pack of 30 panel pins

Follow the main Hideaway installation instructions to point 4 then for point 5 note the following:-

- 1) Insert the vertical fingers of the special, wider floor plates into the ends of the steel wrapped studs. For the H42 kit use 3 floor plates and for H36 and H30 kits use 2 floor plates.
Before fixing the steel wrapped studs:-
Cut the two 20mm wide plywood spacers to length as indicated in diagram below.
Using panel pins fix the 20mm wide plywood to side of header. Repeat on other side.
- 2) Take the two 60mm wide spacers, cut to length if necessary, and using panel pins, nail these onto the header side batten. Repeat on other side.
- 3) Revert to main fixing instructions

