



From the inside of the door insert the two metal thread screws through the lock case & screw into the outside rose. Do not over tighten.