



**ELECTRICITY**  
**1G & 2G**  
**UK PLUG SOCKET**

UK-SO-CO-1G-\*\*-A  
UK-SO-CO-2G-\*\*-A



**BUSTERANDPUNCH.COM**

### PLUG SOCKET TECHNICAL SPEC.

#### PLUG SOCKET STYLE:

13A DP SWITCHED SOCKET.  
RATED AT 13A 250V~

### IMPORTANT NOTES

#### Please read before installing.

These products must be installed in accordance with the latest Building and IEE wiring regulations. If in any doubt, please contact a qualified electrician.

### BACK BOXES

We recommend you to use a UK back box to install your product. Back boxes are available to purchase from us, please see recommended sizes below:

SOCKET PLATE	RECOMMENDED BACK BOX
1G	1G UK Back box – SKU# ELB921
2G	2G UK Back Box – SKU# ELB922

### RECYCLING ELECTRICAL PRODUCTS

Buster and Punch encourages all of its customers to make note of this symbol and avoid putting any waste electrical goods in your domestic waste bin or container. Please ensure you take your waste electrical goods to a suitable facility for disposal.



### INSTALLATION

1. Before commencing work, isolate the mains power supply and remove the fuse in the fuse box or switch off the circuit breaker in the consumer unit.




**CAUTION:**  
Verify power is OFF to switch before proceeding.

2. If unit is to be used as a replacement for an existing product, remove existing unit from its location and disconnect the wiring.


3. Please note that the minimum recommended depth for the mounting box is 35mm. Please ensure that the moulding plate screws are sufficiently tightened to support the product, but do not over-tighten.

4. Connect the wires as shown in appropriate wiring diagram below. Use green/yellow sleeving on earth conductors that are not insulated. Ensure terminals are properly tightened and no bare wire is visible. Push back unit into moulding box making sure conductors are not trapped.

#### 1 GANG 13A D.P. SWITCHED SOCKET



#### 2 GANG 13A D.P. SWITCHED SOCKET



6. Screw the unit to the mounting box using screws provided. Do not over tighten fixing screws. If supplied, fit the screw cover caps by carefully inserting & pressing inwards into the fixing screw holes.

7. To reduce the risk of discolouration or tarnishing, avoid installation on wet plaster.

8. Turn power back on.

